



SANTANA - 09440-12004 - MUELLE RESPIRADERO

Muelle respiradero

SPRING
RESSORT

Vehículo Códigos de modelo Código de modelo Fecha del modelo desde spec

Samurai/SJ SJ410 SJ410K-3/SJ410P-3 (E24) TYPE 3
Samurai/SJ SJ410 SJ410P-4 (E01) SJ410P TYPE 4
Samurai/SJ SJ410 SJ410V-2 SJ410V TYPE 2
Samurai/SJ SJ410 SJ410V-3 (E01) SJ410V TYPE 3
Samurai/SJ SJ410 SJ410V-4 (E01) SJ410V TYPE 4
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1994) 94 MODEL
Samurai/SJ SJ413 SJ413-MIL (Santana)
Samurai/SJ SJ413 SJ413/SJ413Q/SJ413V (E24) TYPE 1
Samurai/SJ SJ413 SJ413V-7 (E24) TYPE 7
Samurai/SJ SJ413 SJ413W-4 (E24) TYPE 4
Carry/Supercarry/Every GA413 GA413-2 AT TYPE 2
Carry/Supercarry/Every SK410 SK410-4
Jimny SN413 SN413V-3 SN413V TYPE 3 PETROL
Carry/Supercarry/Every ST90 ST90V ST90V TYPE 1
Samurai/SJ SJ410 SJ410W (E01) TYPE 1
Samurai/SJ SJ413 SJ413K-3 (E01) TYPE 3
Samurai/SJ SJ413 SJ413Q-4/SJ413V-4/SJ413W-4 (E01) TYPE 4
Samurai/SJ SJ413 SJ413W-2 (E24) TYPE 2
Ignis RG413 RG413-4 RG413
Ignis RM415 RM415 (Magyar) RM415
Samurai/SJ SJ410 SJ410/SJ410Q (E02,E15,E18,E19,E22,E25,E34,E39,E46) TYPE 1
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1988 1/2)
Samurai/SJ SJ419 SJ419 (MY:99, Santana)
Samurai/SJ SJ419 SJ419D (MY:99, Santana)
Samurai/SJ SJ419 SJ419TD (MY:99, Santana)
Jimny SN413 SN413Q-4 (SANTANA) SN413Q
Samurai/SJ SJ410 SJ410-5 (E01) SJ410 TYPE 5
Samurai/SJ SJ410 SJ410K-2 SJ410K TYPE 2
Samurai/SJ SJ410 SJ410W-2 (E01) TYPE 2
Samurai/SJ SJ413 SJ413 (Santana) (E22)
Samurai/SJ SJ413 SJ413K (E28)
Samurai/SJ SJ413 SJ413P-2 (E01) TYPE 2
Samurai/SJ SJ413 SJ413W-3 (E01) TYPE 3

WagonR+ RB310 RB310 (Magyar) RB310 TYPE 1
WagonR+ RB310 RB310-4 (Magyar) RB310
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1990) 90 MODEL
Carry/Supercarry/Every SK410 SK410-3 (E01)
Jimny SN413 SN413V PETROL
Samurai/SJ SJ410 SJ410P-3 (E01) SJ410P TYPE 3
Samurai/SJ SJ413 SJ413-8 TYPE 8
Samurai/SJ SJ413 SJ413K-2/SJ413P-2 (E24) TYPE 2
Samurai/SJ SJ413 SJ413V (E01) TYPE 1
Sierra MG410 MG410/MG410W
Kei RE306 RE306-6 TYPE 6
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1988) 88 MODEL
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1991) 91 MODEL
Jimny SN413 SN413V-2 (SANTANA) TYPE 2 PETROL
Carry/Supercarry/Every ST90 ST90V-2 ST90V TYPE 2
LJ80 LJ81 LJ81K-2/LJ81P-2
Samurai/SJ SJ410 SJ410K (E28:MY 1984) 84 MODEL SJ410K
Samurai/SJ SJ410 SJ410V (E01) SJ410V TYPE 1
Samurai/SJ SJ410 SJ410V (E28:MY 1982) 82 MODEL SJ410V
Samurai/SJ SJ413 SJ413-9 TYPE 9
Samurai/SJ SJ413 SJ413K/SJ413P (E24) TYPE 1
Samurai/SJ SJ413 SJ413V-3 (E01) TYPE 3
Samurai/SJ SJ410 SJ410-2 SJ410 TYPE 2
Samurai/SJ SJ410 SJ410K-5 (E01) SJ410K TYPE 5
Samurai/SJ SJ410 SJ410P-5 (E01) SJ410P TYPE 5
Samurai/SJ SJ413 SJ413 E-III (Santana)
Samurai/SJ SJ413 SJ413-3/SJ413Q-3/SJ413V-3 (E24) TYPE 3
Samurai/SJ SJ413 SJ413P-3 (E01) TYPE 3
Samurai/SJ SJ413 SJ413W-2 (E01) TYPE 2
Samurai/SJ SJ410 SJ410-3/SJ410Q-3/SJ410V-3 (E24) TYPE 3
Samurai/SJ SJ410 SJ410K (E02,E15,E18,E19,E22,E25,E34,E39,E46) TYPE 1
Samurai/SJ SJ410 SJ410K-3 (E01) SJ410K TYPE 3
Samurai/SJ SJ410 SJ410W (E28:MY 1984) 84 MODEL SJ410W
Samurai/SJ SJ413 SJ413W-3 (E24) TYPE 3
Jimny SN413 SN413V-7 (E02,E05,E10,E11,E21,E22,E24,E37,E38,E42,E43,E54,E85,E90,E96) SN413V
TYPE 7 PETROL
WagonR+ RB413 RB413-4 (Magyar) RB413
Ignis RG413 RG413-3 TYPE 3
Carry/Supercarry/Every GE306 GE306-6 TYPE 6
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1989) 89 MODEL
Jimny SN415 SN415QD (SANTANA) DIESEL
WagonR+ SR410 SR410-2 SR410
Samurai/SJ SJ410 SJ410Q-4 (E01) SJ410Q TYPE 4
Samurai/SJ SJ410 SJ410V (E28:MY 1984) 84 MODEL SJ410V
Samurai/SJ SJ413 SJ413Q-7 (E24) TYPE 7
Jimny SN413 SN413V-7 (E06) PETROL
Kei RE306 RE306-5 TYPE 5
Ignis RM413 RM413 (Magyar) RM413

Samurai/SJ SJ410 SJ410/SJ410Q (E28:MY 1983) 83 MODEL
Carry/Supercarry/Every GA413 GA413-5 AT TYPE 5
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1986) 86 MODEL
WagonR+ SR412 SR412-2 SR412
Samurai/SJ SJ410 SJ410V (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98) TYPE 2
Samurai/SJ SJ413 SJ413/SJ413Q (E28)
Samurai/SJ SJ413 SJ413K-3/SJ413P-3 (E24) TYPE 3
Samurai/SJ SJ413 SJ413Q (E01) TYPE 1
Samurai/SJ SJ413 SJ413Q-2 (E01) TYPE 2
Samurai/SJ SJ413 SJ413V (E28)
Jimny SN413 SN413V-5 SN413V TYPE 5 PETROL
Jimny SN413 SN413V-6 (E02,E05,E10,E11,E21,E22,E24,E37,E38,E42,E43,E54,E85,E90,E96) SN413V
TYPE 6 PETROL
WagonR+ RB310 RB310-2 (Magyar) RB310 TYPE 2
WagonR+ RB413 RB413-2 (Magyar) RB413 TYPE 2
Samurai/SJ SJ410 SJ410 (E01) SJ410 TYPE 1
Carry/Supercarry/Every GE306 GE306 TYPE 1
Carry/Supercarry/Every SK408 SK408-2 TYPE 2
Jimny SN413 SN413V-3 (SANTANA) SN413V PETROL
Samurai/SJ SJ410 SJ410-3 (E01) SJ410 TYPE 3
Samurai/SJ SJ410 SJ410-4/SJ410Q-4/SJ410V-4 (E24) TYPE 4
Samurai/SJ SJ413 SJ413-2/SJ413Q-2/SJ413V-2 (E24) TYPE 2
Samurai/SJ SJ413 SJ413K (E01) TYPE 1
Samurai/SJ SJ413 SJ413Q-3 (E01) TYPE 3
Jimny SN413 SN413V-6 (E50) TYPE 6 PETROL
Kei RE306 RE306 TYPE 1
Carry/Supercarry/Every GA413 GA413-3 AT TYPE 3
Carry/Supercarry/Every GA413 GA413-4 AT TYPE 4
Carry/Supercarry/Every GE306 GE306-4 TYPE 4
Samurai/SJ SJ410 SJ410-4 (E01) SJ410 TYPE 4
Samurai/SJ SJ410 SJ410K/SJ410P (E01:TYPE 2) TYPE 2
Carry/Supercarry/Every SK410 SK410-2 (E24) TYPE 2
Samurai/SJ SJ410 SJ410Q-5/SJ410V-5 (E24) TYPE 5
Samurai/SJ SJ410 SJ410V (E28:MY 1983) 83 MODEL SJ410V
Samurai/SJ SJ410 SJ410W (E28:MY 1983) 83 MODEL SJ410W
Samurai/SJ SJ413 SJ413Q-4/SJ413V-4 (E24) TYPE 4
Samurai/SJ SJ413 SJ413V-2 (E01) TYPE 2
Jimny SN413 SN413V-4 SN413V TYPE 4 PETROL
Carry/Supercarry/Every SK408 SK408 TYPE 1
Carry/Supercarry/Every SK410 SK410 (E24) TYPE 1
Carry/Supercarry/Every SK410 SK410-3 (E24)
Samurai/SJ SJ410 SJ410K (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98) TYPE 2
Samurai/SJ SJ410 SJ410V (E02,E15,E18,E19,E22,E25,E34,E39,E46) TYPE 1
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1993) 93 MODEL
Samurai/SJ SJ413 SJ413 (Santana) (E01)
Samurai/SJ SJ413 SJ413-3 (E01) TYPE 3
Samurai/SJ SJ413 SJ413P (E01) TYPE 1
Jimny SN413 SN413V-4 (SANTANA) SN413V PETROL

WagonR+ RB413 RB413D-4 (Magyar) RB413D
Kei RE306 RE306-4 TYPE 4
Kei RE306 RE306-7 TYPE 7
Kei RE306 RE306-8 TYPE 8
Ignis RG413 RG413 TYPE 1
WagonR+ RB413 RB413 (Magyar) RB413 TYPE 1
Kei RE306 RE306-2 TYPE 2
Jimny SN413 SN413Q-3 (SANTANA) SN413Q
Samurai/SJ SJ410 SJ410/SJ410Q (E28:MY 1984) 84 MODEL
Samurai/SJ SJ410 SJ410/SJ410Q/SJ410V (E01:TYPE 1) TYPE 1
Carry/Supercarry/Every GA413 GA413-6 AT TYPE 6
Carry/Supercarry/Every ST90 ST90-3 ST90 TYPE 3
Carry/Supercarry/Every ST90 ST90K-2 ST90K TYPE 2
Samurai/SJ SJ410 SJ410K (E28:MY 1982) 82 MODEL SJ410K
Samurai/SJ SJ410 SJ410Q (E01) SJ410Q TYPE 1
Samurai/SJ SJ410 SJ410Q-2 SJ410Q TYPE 2
Samurai/SJ SJ410 SJ410Q-3 (E01) SJ410Q TYPE 3
Samurai/SJ SJ410 SJ410W-5 (E01) SJ410W TYPE 5
Samurai/SJ SJ413 SJ413Q-5/SJ413V-5 (E01) TYPE 5
Jimny SN413 SN413V-7 (E50) TYPE 7 PETROL
Jimny SN413 SN413V-8 (E02,E05,E10,E11,E21,E22,E24,E37,E38,E42,E43,E54,E85,E90,E96) SN413V
TYPE 8 PETROL
WagonR+ RB413 RB413-3 (Magyar) RB413
Kei RE306 RE306-3 TYPE 3
Ignis RM413 RM413D (Magyar) RM413D
Carry/Supercarry/Every GA413 GA413 TYPE 1
Samurai/SJ SJ410 SJ410K-4 (E01) SJ410K TYPE 4
Samurai/SJ SJ410 SJ410K-5/SJ410P-5 (E24) TYPE 5
Samurai/SJ SJ410 SJ410K/SJ410P (E01:TYPE 1) TYPE 1
Samurai/SJ SJ410 SJ410Q-5 (E01) SJ410Q TYPE 5
Samurai/SJ SJ410 SJ410V-5 (E01) SJ410V TYPE 5
Samurai/SJ SJ413 SJ413Q-6 (E24) TYPE 6
Samurai/SJ SJ413 SJ413Q-7/SJ413V-7 (E01) TYPE 7
Samurai/SJ SJ413 SJ413V-6 (E24) TYPE 6
Samurai/SJ SJ413 SJ413W (E28)
LJ80 LJ80 LJ80/LJ80Q/LJ80V
Samurai/SJ SJ410 SJ410/SJ410Q/SJ410V (E01:TYPE 2) TYPE 2
Carry/Supercarry/Every GA413 GA413-3 TYPE 3
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1987) 87 MODEL
Carry/Supercarry/Every ST90 ST90K ST90K TYPE 1
Samurai/SJ SJ410 SJ410K (E01) SJ410K TYPE 1
Samurai/SJ SJ410 SJ410K-4/SJ410P-4 (E24) TYPE 4
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1995) 95 MODEL
Samurai/SJ SJ413 SJ413Q-6/SJ413V-6 (E01) TYPE 6
Jimny SN413 SN413V-8 (E50) TYPE 8 PETROL
LJ80 LJ81 LJ81K
Ignis RG413 RG413-2 TYPE 2
Samurai/SJ SJ410 SJ410 (Santana)

Carry/Supercarry/Every GA413 GA413-4 TYPE 4
Carry/Supercarry/Every SK410 SK410 (E01) TYPE 1
Jimny SN413 SN413Q (SANTANA) TYPE 1
Samurai/SJ SJ410 SJ410K (E28:MY 1983) 83 MODEL SJ410K
Samurai/SJ SJ410 SJ410P SJ410P TYPE 1
Samurai/SJ SJ410 SJ410P-2 SJ410P TYPE 2
Samurai/SJ SJ410 SJ410W-3 (E01) SJ410W TYPE 3
Carry/Supercarry/Every ST90 ST90-2 ST90 TYPE 2
Samurai/SJ SJ410 SJ410W-4 (E01) SJ410W TYPE 4
Samurai/SJ SJ413 SJ413-2 (E01) TYPE 2
Samurai/SJ SJ413 SJ413K-2 (E01) TYPE 2
Samurai/SJ SJ413 SJ413Q-5/SJ413V-5 (E24) TYPE 5
LJ80 LJ80 LJ80-2/LJ80Q-2/LJ80V-2
Samurai/SJ SJ410 SJ410/SJ410Q (E28:MY 1982) 82 MODEL
Carry/Supercarry/Every GA413 GA413-2 TYPE 2
Samurai/SJ SJ413 SJ413 (E01) TYPE 1
Samurai/SJ SJ413 SJ413 (E03,E33:MY 1992) 92 MODEL
Samurai/SJ SJ413 SJ413W (E01) TYPE 1
Jimny SN413 SN413Q-2 (SANTANA) TYPE 2
Jimny SN413 SN413V-2 SN413V TYPE 2 PETROL
Carry/Supercarry/Every ST90 ST90 ST90 TYPE 1
Carry/Supercarry/Every ST90 ST90K-3 ST90K TYPE 3
Carry/Supercarry/Every ST90 ST90V-3 ST90V TYPE 3
WagonR+ RB310 RB310-3 (Magyar) RB310
Samurai/SJ SJ410 SJ410/SJ410Q (E02,E06,E15,E16,E18,E19,E22,E25,E34,E39,E46,E54,E98) TYPE 2
Carry/Supercarry/Every GE306 GE306-5 TYPE 5
Samurai/SJ SJ410 SJ410W-3 (E24) TYPE 3
Samurai/SJ SJ413 SJ413W (E24) TYPE 1
Carry/Supercarry/Every SK410 SK410-2 (E01) TYPE 2
Ignis RG415 RG415-4 RG415
Jimny SN413 SN413V-9 (E02,E05,E06,E21,E22,E24,E38,E42,E90) SN413V TYPE 9
Jimny SN413 SN413V-9 (E37) SN413V TYPE 9
Jimny SN413 SN413V-9 (E10,E85,E96) SN413V TYPE 9
Jimny SN413 SN413V-9 (E43) SN413V TYPE 9
Jimny SN413 SN413V-9 (E50) TYPE 9 PETROL
Jimny SN413 SN413V-9 (E85) SN413V TYPE 9

