



SUZUKI - 09269-35009-000 - RODAMIENTO 35X72X16.5

Rodamiento

BEARING 35X72X16.5

ROULEMENT 35X72X16.5

Vehículo Códigos de modelo Código de modelo

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1994) 94 MODEL

Samurai/SJ SJ413 SJ413V-7 (E24) TYPE 7

Samurai/SJ SJ413 SJ413W-4 (E24) TYPE 4

Jimny SN413 SN413V-3 SN413V TYPE 3 PETROL

Samurai/SJ SJ413 SJ413Q-4/SJ413V-4/SJ413W-4 (E01) TYPE 4

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1988 1/2)

Samurai/SJ SJ419 SJ419 (MY:99, Santana)

Samurai/SJ SJ419 SJ419D (MY:99, Santana)

Samurai/SJ SJ419 SJ419TD (MY:99, Santana)

Jimny SN413 SN413Q-4 (SANTANA) SN413Q

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1990) 90 MODEL

Jimny SN413 SN413V PETROL

Jimny SN415 SN415QD-3 (SANTANA) DIESEL SN415QD

Jimny SN415 SN415VD-6 DIESEL SN415VD TYPE 6

Samurai/SJ SJ413 SJ413-8 TYPE 8

Sierra MG410 MG410/MG410W

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1988) 88 MODEL

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1991) 91 MODEL

Jimny SN413 SN413V-2 (SANTANA) TYPE 2 PETROL

Samurai/SJ SJ413 SJ413-9 TYPE 9

Samurai/SJ SJ413 SJ413 E-III (Santana)

Jimny SN413 SN413V-7 (E02,E05,E10,E11,E21,E22,E24,E37,E38,E42,E43,E54,E85,E90,E96) SN413V TYPE 7 PETROL

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1989) 89 MODEL

Jimny SN415 SN415QD (SANTANA) DIESEL

Jimny SN415 SN415VD-4 DIESEL SN415VD TYPE 4

Samurai/SJ SJ413 SJ413Q-7 (E24) TYPE 7

Jimny SN413 SN413V-7 (E06) PETROL

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1986) 86 MODEL

Jimny SN413 SN413V-5 SN413V TYPE 5 PETROL

Jimny SN413 SN413V-6 (E02,E05,E10,E11,E21,E22,E24,E37,E38,E42,E43,E54,E85,E90,E96) SN413V

TYPE 6 PETROL

Jimny SN413 SN413V-3 (SANTANA) SN413V PETROL

Jimny SN413 SN413V-6 (E50) TYPE 6 PETROL

Jimny SN415 SN415VD-4 (SANTANA) DIESEL SN415VD

Samurai/SJ SJ413 SJ413Q-4/SJ413V-4 (E24) TYPE 4

Jimny SN413 SN413V-4 SN413V TYPE 4 PETROL

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1993) 93 MODEL

Samurai/SJ SJ413 SJ413 (Santana) (E01)

Jimny SN413 SN413V-4 (SANTANA) SN413V PETROL

Jimny SN413 SN413Q-3 (SANTANA) SN413Q

Jimny SN415 SN415VD-5 DIESEL SN415VD TYPE 5

Samurai/SJ SJ413 SJ413Q-5/SJ413V-5 (E01) TYPE 5

Jimny SN413 SN413V-7 (E50) TYPE 7 PETROL

Jimny SN413 SN413V-8 (E02,E05,E10,E11,E21,E22,E24,E37,E38,E42,E43,E54,E85,E90,E96) SN413V
TYPE 8 PETROL

Samurai/SJ SJ413 SJ413Q-6 (E24) TYPE 6

Samurai/SJ SJ413 SJ413Q-7/SJ413V-7 (E01) TYPE 7

Samurai/SJ SJ413 SJ413V-6 (E24) TYPE 6

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1987) 87 MODEL

Jimny SN415 SN415VD-7 DIESEL SN415VD TYPE 7

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1995) 95 MODEL

Samurai/SJ SJ413 SJ413Q-6/SJ413V-6 (E01) TYPE 6

Jimny SN413 SN413V-8 (E50) TYPE 8 PETROL

Jimny SN413 SN413Q (SANTANA) TYPE 1

Samurai/SJ SJ413 SJ413Q-5/SJ413V-5 (E24) TYPE 5

Samurai/SJ SJ413 SJ413 (E03,E33:MY 1992) 92 MODEL

Jimny SN413 SN413Q-2 (SANTANA) TYPE 2

Jimny SN413 SN413V-2 SN413V TYPE 2 PETROL

Jimny SN415 SN415QD-4 (SANTANA) DIESEL SN415QD

Jimny SN413 SN413V-9 (E02,E05,E06,E21,E22,E24,E38,E42,E90) SN413V TYPE 9

Jimny SN413 SN413V-9 (E37) SN413V TYPE 9

Jimny SN413 SN413V-9 (E10,E85,E96) SN413V TYPE 9


Jimny SN413 SN413V-9 (E43) SN413V TYPE 9

Jimny SN413 SN413V-9 (E50) TYPE 9 PETROL

Jimny SN413 SN413V-9 (E85) SN413V TYPE 9



FIGURE 1



SA413V-5 E22 111
REAR AXLE